

## GPS Unit – Soleta GMAX

### Settings

2-17-21

#### Function Buttons

- Pwr On: Press and Hold ON button to turn on
- Pwr Off: Press ON button then Center button
- Once ON the display will cycle through:
  - o Lat/Long (deg, min)
  - o Direction (true north)/Pitch (deg)/Roll (deg)
  - o Speed (mph)/Altitude (ft)
  - o UTC Time/Date
- Center button - double click
  - o Lat/Long (deg, min)
  - o Direction (mag north)/Pitch (deg)/Roll (deg)
  - o Speed (mph)/Altitude (ft)
  - o Speed (mph)/Heading (deg)
  - o UTC Time/Date
  - o Unit Temp (F)/Baro Press (in Hg)
  - o SET 7 flashing, push center button then up/down buttons to enter a setting. Press Pwr button to save and/or exit the custom settings.
    - SAT: **GPS bds**
    - GEO diSP: **deg/min/sec**
    - INDOOR: **LOCK**
    - bACK LED: **OFF** or **ON**, **dELAY/1 MIN**
    - STATE LED: **ON**, displays signal acquisition and Bluetooth status
    - bEEP: **ON**
    - dIR : **ON**, enables compass direction
    - MAGNET CAL, push center to start calibration: **OK**
    - Compass set for TN or MN: **000 deg /E TN**, check against an accurate reading
    - GPR CAL(Pitch/Roll): Check for 0 deg in pitch/roll
    - SPEEd: **KNOT**
    - ALT: **GPS/FT**, calculation method GPS or AIR
    - Time, UTC: **U**
    - Date: **mm dd YYYY**
    - Temperature: **F**
    - Pressure: **inHg**
    - Auto Set: **FRE:10min/CON:1min**, GPS accuracy check
    - Clock Set: **FRE:1hr/CON:1min**, clock accuracy check
    - FAT3829Mb (logging memory /interval)
    - SET bLE (bluetooth): **OFF**
    - Time/Date Function (timer release setting)
    - bAT : battery voltage
    - SAT v01, bLE v1-2-4 (firmware)
    - SET RESTORE 7, press center button to restore original settings. Press center button to save any custom settings that have not been previously saved.